

For proper CCUA GIS system integration, it is necessary that all polylines be 'flattened' (made to have 0 elevations) prior to saving the drawing for submission; below are a couple of examples of how this can be achieved:

To Flatten all polylines, select all polylines in model space and in the Properties dialog box, set the Z-values/elevations to 0 for proper import into the CCUA GIS system.

